

A566

Super Fast Accelerator

10252016

DESCRIPTION

A566 Super Fast Accelerator is designed to speed up the cure rate of a 2K-urethane topcoat. We find that depending on humidity and temperature, the pot life will be compromised.

COMPONENTS

- A566 Super Fast Accelerator

MIXING RATIO

To one (1) quart of ready-to-spray 2K Urethane color or clear, add up to ¼ ounce of A566. If more is used, topcoat dieback and pinching can occur. Do not use in NorthStar 990 Series Basecoat.

POT LIFE AT 77° F

Pot life will vary depending on the amount used, ambient temperature, and humidity. Do not delay application once A566 has been added and clean equipment immediately.

CLEAN UP

Use NORTHSTAR Lacquer thinner or zero VOC solvents. (Check local regulations)

PHYSICAL DATA

See MSDS

DRY / FLASH TIMES

Adding A566 to your coating can change apparent flash time and will accelerate cure rate and Pot Life.

APPLICATION

Note : Use the proper application instructions for the system you are using this additive in. Do not delay application and clean up immediately.

SAFETY

Refer to Material Safety Data Sheet (MSDS) for complete safety instructions. The technical data sheet listed has been compiled in good faith for your convenience and guidance. No warranty, expressed or implied, is intended or given by the information on this sheet.